



Supaloop Aerial

IL-AE97-00

This aerial is built into the blue loop sign, designed to be used in our Above the Counter Loop Kit [IL-K300-25-00].

The aerial transmits a magnetic field when connected to the 1 to 1 Hearing Loop Driver [HLD2], enabling the telecoil in a hearing aid to receive a signal from drivers.

The aerial should be positioned within 800mm from the user's hearing aid; it can be fixed in place using double sided tape, cable ties, or its stand on top of a flat surface.

Features

- Magnetic field range approximately 800mm

Physical Data

Dimensions	Height - 205mm (8.07") Width - 205mm (8.07") Depth - 5.4mm (0.21") Connection cable length - 2m (78.74")
Weight	200g (0.44lbs)
Construction	Various
Finish	Various

Applications

For use in any situation where one to one communication takes place at a counter, booth or desk, such as in:

- Banks
- Post offices
- Supermarkets
- Theatres
- Information centres
- Airports

Personalisation

Personalised colours to match with your brand are available. Please contact us for more details.

Talk to us now:
+44 (0) 1732 223900 (UK & ROW)
+1 616 392 3400 (US & Canada)
www.contacta.co.uk

